

Pass box



ST-PB60

- Pass box is located on partition walls of clean room and its function is to buffer area for transferring goods between inside and outside of clean room.
- This can prevent any disturbance of airflow and air pressure in clean room, which caused by the door opening for goods transferring.
- Furthermore, it can reduce the time for operators, moving in and out, to prevent any dust coming from the outside the clean room.
- There is interlock guard system controlled the inlet and the outlet of UV sterilizer not be opened at the same time, in order to prevent cross contamination.

Standard features of pass box

- Mechanical/Automatic interlocking for the doors
- Swing type doors with viewing panel
- Door open indicator
- Optional UV lamp

Construction:

- Full Stainless steel structure
- Dimension External : 610W x 610H x 610D mm / 850W x 850H x 1000D mm
- Dimension Internal : 470W x 530H x 540D mm / 710W x 770H x 930D mm

Accessories:

- Firing Base
- Tube Connectiong Socket